



SYS76992VGGA 简易说明书

1、System Board Layout




2、Connectors:

Label	Connectors
JPC1/JPC2	Pin 9 Switch Headers for COM5/COM6
JFRONT_USB1	Header for USB 3.0 Ports
SATA1 ~ SATA2	Serial ATA Header
PCI1	PCI Slot
PE1	Mini PCI-E Slot
JDIO1	Digital I/O Connector
SYS_FAN1	System fan header
CPU_FAN1	CPU fan header
JCMOS1	Clear CMOS setting
JPANEL1	Front Panel Header
F_AUDIO1	Front Panel Audio Header
JAT-ATX	AT/ATX Power Switch Header
JPRNT1	Printer Port Connector

3、Jumper List




Jumper	Function
JPC1/JPC2	Pin 9 Switch Headers for COM5/COM6
JAT-ATX	AT/ATX Power Switch Header
JCMOS1	Clear CMOS Header

4、Front Panel Connector setting :




Pin	Define	Function	Pin	Define	Function	 JPANEL1
1	Key	N/A	2	Power LED+	Power LED	
3	HD LED+	HDD LED	4	Power LED+		
5	HD LED-		6	Power LED-		
7	Reset	Reset Button	8	Power	Power Button	
9	GND		10	Power GND		

5、Jumper Setting (JCMOS1 and JAT1 and JPC1/JPC2):


A、Clear CMOS setting:



B、AT/ATX Power setting:



C、Pin 9 Switch Headers for COM5/COM6



Checklist:

- SYS76992VGGA Mainboard*1pcs
- Utility CD for SYS76992VGGA*1pcs
- Installation Guide*1pcs
- SATA Cable *2pcs;
- COM cable and Print cable*5pcs
- I/O Shield * 1pcs